

Flecks™ Resilient Rubber Flooring

Maintenance

Flecks Rubber Flooring is designed to require less maintenance than is typically required by other types of flooring. Its black background is made to show little dirt or wear, even in high abuse areas. We suggest that you clean and maintain your floor as regularly as you feel is needed. Depending on the use and your expectations for the flooring, we recommend the following routine maintenance:

- 1) Vacuum to pick up loose dirt.
- 2) Damp Mop with a sponge mop using water alone. A ½ cup of simple Green, Pinesol, or similar non-abrasive cleaner, per one gallon of water solution may also be used. We DO NOT recommend the use of a string mop when cleaning the floor.
- 3) Change water frequently, especially on the initial cleaning after installation.
- 4) Never use an abrasive cleaner – ensure that it is solvent and acid free as well.
- 5) When cleaning fitness equipment with disinfectants or other strong cleaners, take care not to get these chemicals on the floor. These chemicals may cause deterioration over time. If such chemicals are spilled on the floor, rinse the floor with water as soon as you are aware of the spill.

Rotary Scrubbing machine

Rotary Scrubbing machines are not typically necessary to maintain a Flecks floor, but if you have one to maintain other areas, it can be used on the rubber as well, following these guidelines:

- 1) Remove all surface debris by vacuuming or dust mopping.
- 2) Mix a gallon of water with 4 oz. of non-abrasive cleanser.
- 3) Use a sponge mop to dampen the floor with this cleanser mixture before scrubbing.
- 4) Allow solution to sit on the floor for about 10 minutes before scrubbing.
- 5) Use the rotary scrubber over the dampened areas.
- 6) After scrubbing, rinse the floor using clean water.
- 7) Remove excess water from the floor with a wet/dry vacuum for faster drying.